MODEL: 50198SMG

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS FOUNTAIN SHOULD TAKE APPROXIMATELY 15 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

UNPACK THE FOUNTAIN

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS: COLUMN, FOUNTAIN BODY, PUMP, SOLAR PANEL, BRACKET, TUBE, SPIKE AND (2) REMOTE-CONTROL UNITS. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

FOUNTAIN ASSEMBLY

1. FEED THE PUMP POWER CORD AND LED LIGHT POWER CORD THROUGH THE HOLES IN RESERVOIR TOWARD BOTTOM OF FOUNTAIN BODY, CORD EXIT OUT FROM CHANNEL ON THE BOTTOM OF THE FOUNTAIN BODY.



2. FILL RESERVOIR WITH 1.6 GALLONS OF WATER TO COMPLETELY SUBMERSE THE PUMP.

NOTE: DISTILLED WATER IS RECOMMENDED TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD-UP.



3. ATTACH PUMP TO RUBBER HOSE.



MODEL: 50198SMG

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

FOUNTAIN ASSEMBLY

4. PLACE COLUMN WITH PUMP INTO RESERVOIR OF FOUNTAIN BODY.



NOTE: THE SOLAR PANEL CAN BE MOUNTED USING SPIKE OR JUST BE PLACED ON GROUND.

5. JOIN BRACKET, TUBE AND SPIKE TOGETHER, THEN ATTACH BRACKET TO BACK OF THE SOLAR PANEL AS SHOWN.



6. REMOVE PLASTIC STOPPLES FROM THE HOLE FOR PUMP PLUG AND THE HOLE FOR LED LIGHT PLUG.

7. TWIST PUMP PLUG SLIGHTLY AND PUSHING IT INTO THE HOLE FOR PUMP PLUG, THEN TWIST LED LIGHT PLUG SLIGHTLY AND PUSHING IT INTO THE HOLE FOR LED LIGHT PLUG, MAKE SURE THE SEALING RINGS ARE FULLY IN GROOVES.

8. INSERT SPIKE INTO GROUND.



MODEL: 50198SMG

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

FOUNTAIN ASSEMBLY

9. TURN ON THIS FOUNTAIN, YOUR NEW FOUNTAIN IS READY FOR USE.

* PRESS "A" TO TURN ON/OFF THE PUMP AND THE LED LIGHTS. (NOTE: LED LIGHTS ONLY WORK AT NIGHT)

** PRESS "B" TO ADJUST PUMP TO ACHIEVE VARIABLE WATER FLOW.

*** REMOTE-CONTROL UNIT EFFECTIVE DISTANCE: 32 FEET.



TROUBLE SHOOTING:

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK SOLAR PANEL IS IN CORRECT POSITION, RECEIVING SUNLIGHT AND NOT IN SHADOW.

2. CHECK CONNECTIONS BETWEEN THE PUMP/LED AND THE SOLAR PANEL.

3. CHECK WATER LEVEL AND MAKE SURE THE PUMP IS SUBMERGED.

4. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

SPLASHING DISCLAIMER:

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

IMPORTANT PUMP INFORMATION:

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

WATER:

TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

IMPORTANT NOTES:

1. SOLAR PUMP WILL KEEP RUNNING FOR 3 HOURS EACH TIME (3H TIMER) AFTER YOU TURN ON IT.

2. THE LED LIGHTS WILL TURN ON AUTOMATICALLY EVERY NIGHT WHEN THIS FOUNTAIN IS TURNED ON.

3. ALTHOUGH THERE MAY BE SOME INITIAL CHARGE IN BATTERY, WE RECOMMEND FULLY CHARGING IT BEFORE FIRST USE. TURN OFF THE SOLAR PUMP AND LEAVE THE FOUNTAIN IN GOOD SUNLIGHT FOR 6 HOURS TO ENSURE THE BATTERY PACK IS FULLY CHARGED.

4. TO GET BEST PERFORMANCE FROM THE SOLAR PANEL IN THE SUNSHINE, PLEASE MAKE SURE THAT YOU PERIODICALLY CLEAN THE TOP SURFACE OF THE SOLAR PANEL (DO NOT USE A CHEMICAL SOLVENT).

WARNING:

* ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD-UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.

** THIS FOUNTAIN IS RATED FOR OUTDOOR USE.

*** MOVE YOUR FOUNTAIN INTO YOUR ROOM IN FREEZING DAYS TO PROTECT THE FOUNTAIN.

**** IF YOU DO NOT WANT TO USE THIS FOUNTAIN FOR LONG TIME, PLEASE UNPLUG THE PUMP PLUG FROM BOTTOM OF SOLAR PANEL.

PLEASE SEE NEXT PAGE FOR BATTERY PACK REPLACEMENT.

AVAILABLE PARTS ARE:
SPUMP1022S (PUMP)
SPANEL2 (SOLAR PANEL)
BATTERY6V (BATTERY PACK)
SOLARREMOTE1 (REMOTE-CONTROL UNIT)

MODEL: 50198SMG

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

BATTERY PACK INFORMATIONS:

* RECHARGABLE BATTARY PACK BECOME LESS EFFICIENT WITH REPEATED CHARGE AND DISCHARGE CYCLES, THE CAPACITY OF THE BATTERY PACK MAY REDUCE OVER TIME. IF YOU FIND THAT THE BATTERY PACK APPEAR LESS EFFICIENT, TRY TO BOOST CHARGE IT. TO DO THIS, LEAVE OFF THIS FOUNTAIN FOR 2~3 DAYS IN SUNNY DAYS TO ALLOW THE MAXIMUM CHARGE TO THE BATTERY PACK. WE RECOMMEND THAT YOU DO THIS OCCASIONALLY TO HELP PROLONG THE LIFE OF BATTERY PACK. IF YOUR BATTERY PACK STILL DOES NOT WORK WELL AFTER THIS BOOST CHARGE, YOU SHOULD REPLACE THE BATTERY PACK AS BELOW.

** AFTER THE BATTERY PACK USED FOR 12~18 MONTHS, IT MAY HAVE REACHED IT'S SERVICE LIFE, YOU SHOULD REPLACE THE BATTERY PACK.

BATTERY PACK REPLACEMENT INSTRUCTIONS:

1. PULL OUT THE SPIKE AND REMOVE BRACKET FROM BACK OF SOLAR PANEL.



2. REMOVE LED LIGHT PLUG AND PUMP PLUG FROM SOLAR PANEL AS SHOWN.



3. REMOVE COVER FROM SOLAR PANEL BY UNSCREWING (6) SCREWS.



4. DISCONNECT THE CONNECTORS, THEN REPLACE THE OLD BATTERY PACK WITH A NEW BATTERY PACK AND JOIN THE CONNECTORS TOGETHER.



5. SECURE THE COVER TO SOLAR PANEL WITH THE (6) SCREWS REMOVED ABOVE.



6. TWIST PUMP PLUG SLIGHTLY AND PUSHING IT INTO THE HOLE FOR PUMP PLUG, THEN TWIST LED LIGHT PLUG SLIGHTLY AND PUSHING IT INTO THE HOLE FOR LED LIGHT PLUG, MAKE SURE THE SEALING RINGS ARE FULLY IN GROOVES.



7. ATTACH BRACKET TO BACK OF THE SOLAR PANEL AND INSERT SPIKE INTO GROUND.



AVAILABLE PARTS ARE:
SPUMP1022S (PUMP)
SPANEL2 (SOLAR PANEL)
BATTERY6V (BATTERY PACK)
SOLARREMOTE1 (REMOTE-CONTROL UNIT)